



IGLAND

User manual

Round Bale

Grapple RBG 150



Read through the entire manual before using the product. It contains important safety information.



nøsted &

Thank you for choosing the Round Bale Grapple from IGLAND!

This user manual is designed to provide you with detailed information on the use, installation, safety, and maintenance of the equipment.

It is important that you read this manual carefully before using the machine.

The safety of our users is our highest priority. This manual contains important information on how to use the machine safely and avoid potential hazards.

To ensure your safety, we want you to be aware of and consider that accidents, misuse, and equipment failure can lead to dangerous situations. It is important that you position yourself during work so that any accident does not result in personal injury.

The instructions provided in this manual must always be followed. Careless or incorrect use can result in serious injury or death. Modifications or other alterations to the original design of the product are made at your own risk and responsibility. It is important to note that any modification or alteration of the product will void the warranty.

If you have any questions or need assistance, please contact our service center at +47 479 20 192. Always state the type, serial number, and year of manufacture when making inquiries and ordering parts.

We are here to help you have a safe and enjoyable user experience.

Product	
IG226100	RBG 150

Revised	01.08.2024
Published	06/22/2023
P/N	IG390422
Website	Nosted.com/igland
Email	corporate@igland-as.com
Phone	+47 372 56 200

Reproduction of text or illustrations without permission is prohibited.

AI-translated from the original user manual

# TABLE OF CONTENTS	PAGE
1. Optional accessories	4
2. Safety instructions	5
2.1. General safety instructions	5
2.2. Safe use	5
2.3. Storage	6
2.4. Checklist before use	6
3. Main components	7
4. Technical specifications	8
4.1. Igland RBG 150	8
5. Installation	8
6. Operation	9
7. Maintenance	9

1. EXTRA EQUIPMENT

Igland RBG 150	
DESCRIPTION	PRODUCT NO.
Mounting bracket for SMS	IG500050
Mounting bracket for HMT and SMS	IG500056
Mounting bracket for Avant/Multione	IG500048
Mounting bracket for Triangle quick coupling	IG500059
Mounting bracket for Triangle quick coupler, reinforced	IG611007
Mounting bracket for 3-point mounting	IG500063
Mounting bracket for 3-point mounting, reinforced, for front and rear mounting	IG500066
Mounting bracket for Scan Frame	IG500044
Mounting bracket for JCB Compact Tool Carrier	IG500043
Mounting bracket for S40 excavator attachment	IG500046
Mounting bracket for S50 excavator attachment	IG500047
Mounting bracket for old Ålø type 3	IG500053
Mounting brackets for Euro combi	IG500062
Mounting brackets for Euro (John Deere)	IG500061
Mounting brackets for John Deere 400/500	IG500067
Mounting brackets for skid steer loaders	IG500064
Mounting brackets for JCB 406-407-409, "Small" Volvo-ZettelMeyer 502-602-702	IG500054
Mounting bracket for Weidemann Hoftrack 1380	IG500049



2. SAFETY INSTRUCTIONS


2.1 General safety instructions To ensure safe use of the attachment, it is important to follow our safety instructions carefully.

- **Read the user manual:** Before using the tool, read and review the user manual carefully to understand its correct use and maintenance.
- **Area of use:** The tool should only be used for lifting and stacking round bales. Never use the product for tasks other than those for which it is designed. The manufacturer is not liable for damage or destruction caused by misuse of the equipment.
- **Safety distance:** Respect the safety zone of 10 m.
- **Operation:** Familiarize yourself thoroughly with the functions of the product. Ensure that only qualified and trained persons use the equipment. Exercise the utmost caution at all times.
- **Personal protective equipment:** Always use the necessary personal protective equipment.
- **Risk of crushing:** Be aware of the risk of crushing from all moving parts.
- **Emergency preparedness:** Keep first aid equipment and emergency numbers readily available in case of an accident or emergency.
- **Modifications or other alterations** to the original design of the product are made at your own risk and responsibility. It is important to note that any modification or alteration of the product will void the warranty.
- **Inspect the product** for signs of wear, damage, or loose parts and screws. Replace worn or damaged parts with components approved by the manufacturer. All damage must be repaired before the product can be used again.
- **Keep a record of maintenance and repairs** performed on the product.



2.2 Safe use

- **Follow safety rules and exercise the utmost caution** to limit and prevent accidents.
- **Ensure that the product is in good condition before use** and that it has undergone regular maintenance checks.
- **Ensure that all warning signs** are visible and legible at all times.
- **The implement is operated** from the tractor cab.
- **Must only be used** on the tractor's 3-point hitch or loading device.
- **During transport**, the load **must** be secured with additional lashing.
- **Always take into account** the weight distribution and stability of the tractor or load.
- **Avoid lifting high**, as this may cause the tractor to tip over.
- **Keep the load as low** as possible with a low center of gravity.
- **Never stand** between the tractor and the implement.
- **Avoid wearing scarves and other loose clothing** that could get caught in moving parts.
- **Do not overload** the product's capacity and always follow the manufacturer's recommendations.
- **Maximum oil pressure 200 bar.** Oil leaks under pressure can cause personal injury.
- **Never walk under** the raised implement.



- **Maintenance must only** be carried out with the engine switched off.
- **Never make adjustments or perform maintenance** on raised implements.
- **Exercise extra caution** when driving on slippery surfaces.
- **Avoid driving on** sloping or inclined terrain.
- Remove **snow, ice, or other foreign objects** before use.

2.3 Storage

- Store the equipment in a dry and secure place.
- Always park on level and firm ground.
- Never leave the machine with the implement raised.
- Prevent children from climbing or playing on or next to the equipment.
- Exercise caution when assembling and disassembling.




2.4 Checklist before use

- Always inspect the product for wear and damage before use. Any damage must be repaired by qualified personnel before the equipment is used again.
- Ensure that you have a full overview of the work area.
- Keep children and pets away from the work area.
- Lubricate the equipment as specified.
- Follow safety rules to limit and prevent accidents.



3. MAIN COMPONENTS



No. Main components

1. Frame
2. Gripper arm
3. Cylinder
4. Locking bolt

4. TECHNICAL SPECIFICATIONS

Igland RBG 150	
Anti-siphon valve	Yes
Cylinder force	6.6 tons
My opening	0 cm
Max opening	192 cm
Weight	175 kg

5. ASSEMBLY

Lift into place in a suitable location.

Install mounting brackets for the relevant loading equipment using the 4 M20 bolts/nuts provided.

Connect to the tractor's loading device.

Secure with the loading device's locking mechanism. Install hydraulic pressure and return hoses. Connect the hoses to the loader's 3rd function.

Use straps to suspend hoses/cables.

Check that moving parts do not come into contact with the hydraulic components.

Avoid unnecessary strain on hoses/cables when the loader is in motion.

Check that there are no hydraulic oil leaks.

6. OPERATION

A safety zone of 10 meters must be observed.

Avoid lifting high, as this may cause the tractor

to tip over. Never leave the machine with the

implement raised.

RBG 150 control levers should only be used while the operator is seated in the tractor.

Take into account the tractor's lifting capacity and weight. Only use for lifting and stacking round bales.

Keep the load as low as possible to ensure a low center of gravity. The round bale is lifted with the arms hanging down to avoid slipping. The round bale is placed with the thickest plastic facing down.

The opening of the gripper arms can be limited if desired by moving the bolt.

One of the gripper arms can be locked in place using 2 bolts if desired.

Park on safe ground, secured against tipping.



6.1 Locking the gripper arm

7. MAINTENANCE

Maintenance must only be carried out with the engine switched off and the implement lowered to the ground.

Interval	Component	Description
First 10 hours	Screws and nuts	Retighten
	Hoses	Check for pinch marks, cracks, wear
Every 50 hours	Moving parts	Lubricate with oil
	Lubrication points	Lubricate with grease
	Hoses	Check for pinch damage, cracks, wear
"Every 100 hours/annually"	Screws and nuts	Retighten

Exercise caution during disassembly. Store the

RBG 150 under cover.



7.1 Lubrication points



7.2 Lubrication points, front

NOTES

A series of horizontal dotted lines for taking notes.

NOTES



IGLAND Workshop and Service Center

Our Workshop and Service Center in Mandal provides technical support for all our products.

We service and repair older and well-used winches. This extends the life of the products and is good for the environment.

Do you need:

Technical support for timber trailers

Accessories or additional equipment

An appointment for service or repair of your winch Call our service office on +47 372 56 200

Email: service.igland@nosted.com

nøsted &

Doneheia 17, 4516 Mandal